

Panasonic Heat Pump / Cooling Unit

An air-to-air heat pump is a very energy-efficient way to generate heat. Feel free to run it continuously in winter; you can set it slightly lower (16 - 18°C) overnight and adjust it back to your desired temperature in the morning.

Particularly good in summer: the unit can also cool.

Operating Tips:

Point the remote control directly at the device. Be patient. Press the buttons slowly! The unit only receives the command when you hear a BEEP. After you make a new adjustment, wait – it always takes a while for the device to execute the command.



1 - ON / OFF

Make sure the HEAT mode is activated

2 - MODE

If necessary, you can switch the mode here

HEAT	DRY
COOL	FAN

3 - Display

Here you can see mode, target temperature, time, and fan speed.

4 - Temperature

Use the arrow buttons to adjust the temperature.

5 - Quiet mode / rapid heating

Set to QUIET if the airflow is too strong.

Set to POWERFUL if you need fast and strong heating.

Both modes should only be used for short periods.

More info ↩



Important: always WAIT!

The heat pump responds very slowly.

Wait for the remote control command to be acknowledged by a beep.

After a new command, wait 10 minutes to see if the device has received it and is implementing it.

Here are further options:

Generally, the fan speed FAN should be set to automatic = AUTO.

If this is not the case, you can set it yourself.

To do this, pull down the lower part of the cover and you will see another control panel.

The button in the top right FAN SPEED controls the fan speed.

Have a wonderful vacation! 😊
Your Klitferie Team



More info ↪