

Danfoss Underfloorheating



Tap once on the blank standby screen to activate it.



Initial tap: Current temperature



Tap again: Currently set target temperature



Use the arrow keys to change your desired target temperature.



Press the checkmark to confirm the new target temperature.



Once confirmed, the "Heating" status light will turn off if the new target is lower.

Important to know:

It can take up to 24 hours for the sauna to reach your newly set target temperature.